


EN Dishwasher / User Manual



DW8600

CONTENTS

1 IMPORTANT SAFETY INSTRUCTIONS	4
2 INSTALLATION	9
3 TECHNICAL SPECIFICATIONS	11
4 BEFORE USING THE APPLIANCE	12
5 LOADING YOUR DISHWASHER	14
6 PROGRAMS AND OPTIONS TABLE	18
7 THE CONTROL PANEL	19
8 MAINTENANCE AND CLEANING	23
9 TROUBLESHOOTING	26

Thank you for choosing this product.

This user manual contains important information on safety and instructions intended to assist you in the operation and maintenance of your appliance.

Please take the time to read this user manual before using your appliance and keep this book for future reference.

Icon	Туре	Meaning
	WARNING	Serious injury or death risk
<u></u>	RISK OF ELECTRIC SHOCK	Dangerous voltage risk
	FIRE	Warning; Risk of fire / flammable materials
\bigcirc	CAUTION	Injury or property damage risk
	IMPORTANT / NOTE	Operating the system correctly

INTRODUCTION

Please read this user manual and particularly the safety instructions completely and carefully. They will save you time and effort and help to ensure optimum dishwasher performance.

Be sure to observe all listed warnings and cautions. Look particularly for the icons with exclamation marks inside. The information icon will also provide important references.

A WARNING: Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

<u>Properties</u> CAUTION: Indicates a potentially hazardous situation which, if not avoided, may result in injury. It may also be used to alert against unsafe practices.

NOTICE: Indicates a potentially hazardous situation which, if not avoided, may result in damage to the dishwasher, the tableware, the equipment or the environment.

1 IMPORTANT SAFETY INSTRUCTIONS

WARNING: When using the dishwasher, follow basic precations. Read all instructions before using the dishwasher! Save these operating instructions and pass them on to any future user.

- Use the dishwasher only for its intended purpose as described in this user manual. This appliance is intended for normal household use only. Do not change the specification of the appliance. The manufacturer disclaims responsibility for damage or injury caused by improper use of this appliance.
- The information in this user manual must be followed to minimize the risk of fire or explosion and to prevent property damage, personal injury or loss of life
- Use only detergents or wetting agents recommended for use in a dishwasher and keep them out of the reach of children.
- When loading items to be washed.
- 1) Locate sharp items so that they are not likely to damage the door seal, and.
- 2) Load sharp knives with the handles up to reduce the risk of type injuries.
- Do not wash plastic items unless they are marked "dishwasher safe" or the equivalent. For plastic items not so marked, check the manufacturer's recommendations.
- Do not touch the HEATING ELEMENT during or immediately after use.

- Do not operate your dishwasher unless all ENCLOSURE panels are properly in place.
- Do not tamper with controls.
- Do not abuse, sit on, or stand on the door or dish rack of the dishwasher.
- The cup racks are designed to support cups, glasses and kitchen utensils. When the cup racks are in the dishwasher do not lean on or use the cup racks to support your body weight.
- This appliance must be grounded. In the event of a malfunction or breakdown, grounding will reduce the risk of electric shock by providing a path of least resistance for electric current.

A WARNING:

Improper connection of the equipmentgrounding conductor can result in a risk of electric shock. Check with a qualified electrician or service representative if you are in doubt whether the appliance is properly grounded.

• Some dishwasher detergents are strongly alkaline. They can be extremely dangerous if swallowed. Avoid contact with the skin and eyes and keep children and infirm persons away from the dishwasher when the door is open.

Consult a doctor immediately if detergent has been swallowed or inhaled.

- Do not remove the dishes from the appliance until the program is complete. Some detergent may remain on the dishes.
- Check that the detergent dispenser is empty after the completion of each wash program.
- Do not drink and play with the water in the appliance. harmful residues could be present.
- To reduce the risk of injury, do not allow children to play in or on a dishwasher.
- When children become old enough to operate the appliance, it is the responsibility of the parents/legal guardians to ensure the children are instructed in safe practices by qualified persons.
- Do not leave the appliance with the open door unattended to avoid stepping accidentally onto it.

WARNING: Before any maintenance operation, deactivate the appliance and disconnect the mains plug from the socket.

- Do not use high pressure water sprays and/or steam to clean the appliance.
- Ensure that there are no visible water leaks during and after the first use of the appliance.
- To avoid floor damage and possible mold growth, do not allow wet areas to remain around or under the dishwasher.
- To avoid dishwasher damage, do not allow water to remain in your dishwasher systems through extended periods of freezing.

RISK OF INJURY: To avoid risk of injury, always use caution when opening the door during or following a wash cycle as hot water or steam may escape.

- Do not store or use flammable liquids or vapors in the area of the dishwasher, near or on the appliance.
- Under certain conditions, hydrogen gas may be produced in a hotwater system that has not been used for two weeks or more. HYDROGEN GAS IS EXPLOSIVE. If the hot-water system has not been used for such a period, before using the dishwasher turn on all hot-water faucets and let the water flow from each for several minutes. This will release any accumulated hydrogen gas. As the gas is flammable, do not smoke or use an open flame during this time.
- Please check the water supply line periodically. It is susceptible to breakage. It becomes less flexible as time goes by. Replace it immediately when it is torn, cut, swollen or there is water leakage.

RECYCLING

Remove the door to the washing compartment when removing an old dishwasher from service or discarding it. Ensure that the appliance presents no danger to children while being stored for disposal. Before disposing the dishwasher:

- Disconnect the appliance from the mains supply.
- Remove the door catch to prevent children and pets to get closed in the appliance

Old appliances may contain materials that can be recycled. Please contact your local recycling authority about the possibility of recycling these materials.

Please check the water supply line periodically. It is susceptible to breakage. It becomes less flexible as time goes by. Replace it immediately when it is torn, cut, swollen or there is water leakage.

Please keep the dishwasher package out of the reach of children after unpacking it.

WARNING!:

Risk of injury or suffocation! Ensure that any plastic wrappings, bags, small pieces etc. are disposed of safely and kept out of the reach of children.

SAVE THESE INSTRUCTIONS

2 INSTALLATION

WARNING: When installing the dishwasher, follow basic precau-tions, including the following: Please check the standards and local codes for placement of machine.

- Installation, maintenance and repair should be performed by a qualified installer. Work by unqualified persons could be dangerous and may void the warranty.
- Do not operate the appliance if damaged, malfunctioning, partially disassembled or if it has missing or broken parts.
- Before installation or service, disconnect the power supply to the work area by unplugging the unit, "tripping" the circuit breaker or removing the fuse.
- Only connect the dishwasher to the power supply when all installation and plumbing work is complete.
- Never connect the ground wire to gas lines, or hot water pipes, plumbing lines.
- Do not install or store the dishwasher where it can be exposed to below freezing temperatures or exposed to weather.
- Dishwasher must be secured to adjacent cabinetry using the brackets provided. Failure to do this may cause damage to property or bodily injury.
- Connect to a properly rated, protected and sized power supply circuit to avoid electrical overload.
 The dishwasher is designed for an electrical supply


of 120 V (volts), 60 Hz (hertz), AC, connected to a dishwasher-dedicated, properly grounded electrical circuit with a fuse or breakers rated for 15 amperes. Electrical supply conductors shall be a minimum of # 16 AWG copper wire rated at 75 °C (167 °F) or higher. These requirements must be met to prevent injury and machine damage. Consult a qualified electrician if in doubt.

 Do not use any extension cord or portable outlet device to connect the dishwasher to a power supply.

WARNING: Danger of suffocation! Ensure that any plastic wrap-pings, bags, small pieces etc. are disposed of safely and kept out of the reach of children.

3 TECHNICAL SPECIFICATIONS





General Appearance

- 1. Upper basket with racks
- 2. Upper spray arm
- 3. Lower basket
- 4. Lower spray arm
- 5. Top nozzle
- 6. Filters
- 7. Rating plate
- 8. Control panel
- 9. Detergent and rinse-aid dispenser
- 11. Upper basket track latch
- 12. Drying Unit: This system provides better drying performance for your dishes.

Technical Specifications

Permissible water pressure	4.35 - 145 psi (0.3 - 10 bars)
Electrical connection	120 V (volts), 12 A (amps), 60Hz (hertz)
Total power	1400 (W)
Heater power	1100 (W)

NOTICE: Because we continually strive to improve our products, we may change our specifications and design without prior notice. This device corresponds to the following directives: UL 749 Household Dishwasher directive.

4 BEFORE USING THE APPLIANCE

Preparing your dishwasher for first use

- Make sure the electricity and supply water specifications match the values indicated in the installation instructions for the machine.
- Remove all packaging material inside the machine.
- Fill the rinse aid compartment.

Detergent usage

Only use detergents specifically designed for domestic dishwashers. Keep your detergents in cool, dry places out of reach of children.

Add the proper detergent for the selected program to ensure the best performance. The amount of detergent needed depends on the cycle, load size, and soil level of dishes.

Do not fill detergent into the detergent compartment more than required; otherwise you can see whitish streaks or bluish layers on glass and dishes and may cause glass corrosion. Continued use of too much detergent may cause machine damage.


Using little detergent can result in poor cleaning and you can see whitish streaksin hard water.


See the detergent manufacturer's instructions for a further information.

Filling the detergent

Push the latch to open the dispenser and pour in the detergent.

Close the lid and press it until it locks in place. The dispenser should be refilled just before the start of each programme. If the dishes are heavily soiled, place additional detergent in the pre-wash detergent chamber.





Using combined detergents

These products should be used according to the manufacturer's instructions.

Never put combined detergents into the interior section or the cutlery basket.

Combined detergents contain not only the detergent but also rinse-aid, replacement substances and additional components depending on the combination.

We recommend you do not use combined detergents in short programmes. Please use powder detergents in such programmes.

If you encounter problems when using combined detergents, please contact the detergent manufacturer.

When you stop using combined detergents, make sure that water hardness and rinse aid settings are set to the correct level.

Rinse-aid usage

The rinse aid helps to dry the dishes without streaks and stains. Rinse-aid is required for stain-free utensils and clear glasses. The rinse aid is automatically released during the hot rinse phase. If rinse aid dosage setting set too low, whitish stains remains on dishes and dishes do not dry and washed clean. If rinse aid dosage setting set too height, you can see bluish layers on glass and dishes.

Filling the rinse-aid and setting

To fill the rinse aid compartment, open the rinse-aid compartment cap. Fill the compartment with rinse aid to the MAX level and then close the cap. Be careful not to overfill the rinse aid compartment and wipe up any spills.


In order to change the rinse aid level, follow the below steps

- Turn on the machine and press Menu button for 3 seconds. Water hardness level is seen first. ("SL1" is the factory setting)
- Press Delay(+) button to pass Rinse aid setting. ("r:4" is the factory setting)
- Rinse aid follows water hardness setting.
- Then, press Select button and the level of Rinse aid (e.g. "r:4") blinks.
- Change the level by pressing the Delay buttons.
- Press Select button to save desired level and the new level of Rinse aid will illuminate constantly.
- Turn off the machine to exit from the setting.

The factory setting is "4".

If the dishes are not drying properly or are spotted, increase the level. If blue stains form on your dishes, decrease the level.





Level	Level Brightener Dose Indicato	
1	Rinse-aid not dispensed	r:1 is shown on the display.
2	1 dose is dispensed	r:2 is shown on the display.
3	2 doses are dispensed	r:3 is shown on the display.
4	3 doses are dispensed	r:4 is shown on the display.
5	4 doses are dispensed	r:5 is shown on the display.

5 LOADING YOUR DISHWASHER

If you properly place your dishes into the machine, you will be using it in the best way in terms of energy consumption, washing and drying performance.

You can load into the lower basket such round and deep items as pots with long handles, pot lids, plates, salad plates, cutlery sets. The upper basket has been designed for dessert plates, salad bowls, cups and glasses. When placing long stem glasses and goblets, lean them against the basket edge, rack or glass supporter wire and not against other items. Do not lean long glasses against one another or they cannot remain steady and may receive damage. It is more appropriate to locate the thin narrow parts into the middle sections of baskets. You can place spoons among the other cutlery sets in order to prevent them from sticking to one another.

You are recommended to use the cutlery grid in order to obtain the best result. To avoid any possible injuries, always place such long-handle and sharp-pointed dishes as serving fork, bread knife etc. with their sharp points facing down or horizontally on the baskets.

NOTE: Place all large and very dirty items in the lower rack.

/! WARNING: Do not put in the appliance items that can absorb water (sponges,household cloths).

NOTE: Place all containers such as cups, glasses and pots into the dishwasher with the opening facing downwards (so that no water can collect).

NOTE: Dishes and cutlery should not be placed above each other.

NOTE: Do not overload your dishwasher and pay attention to manufacturer instructions regarding dishes which are appropriate for use in a dishwasher. Only with suitable dishes (mentioned in section 5) will you obtain optimal washing results with a sensible use of energy.

High temperature water and dishwasher detergent may form a chemical synthesis that can damage certain items.

WARNING: Be careful when loading and unloading sharp items. Load sharp knives with the handles up to reduce the risk of personal injury.


Follow the below steps before loading dishwasher.

- 1. Open the door.
- 2. Remove coarse food leftovers from tableware.
- 3. Load the dishwasher.

NOTE: While the appliance is running if you open the door all functions are automatically interrupted. Once the door is closed functions will continue to work.

Upper Rack


Load the upper rack with dessert plates, cups, glasses etc.



Top rack load pattern for 8 place settings.

Lower Rack

You can load into the lower basket such round and deep items as pots with long handles, pot lids, plates, salad plates, cutlery sets. The lower rack should not be used for small items such as cups, wine glasses.



NOTE: Place all large and very dirty items in the lower rack.

WARNING: Large knives and other utensils with sharp tips and edges must be placed horizontally into the upper rack due to risk of injury. Other smaller knives and sharp utensils should be placed with sharp side down in the cutlery basket.

NOTE: Make sure that large items do not interfere with the rotation of the spray arms, and do not prevent the detergent dispenser from opening.

Loading cutlery basket (Model Depending)


1- Serving spoons 2- Dinner forks 3- Knives 4- Tea spoons 5- Serving forks 6- Salad forks Silverware basket loading pattern for 8 place settings.


WARNING: Sharp cutlery may have shifted position during the wash operation and can be also wet and slippery. Carefully remove them to prevent injury.


NOTE: Small items should therefore be placed in the cutlery tray or cutlery basket (model depending). Because small items can fall through the holders from the baskets.


Incorrect Loads

Incorrect loading can cause poor washing and drying performance. Please follow the manufacturer's recommendations for a good performans result.









6 PROGRAMS AND OPTIONS TABLE

Programs		Duration (min)	Descriptions
Dogular	Dirty	145	Standard program for daily, regular or typical use to
Regular	Clean	122	completely wash a load of normally soiled dishes.
Auto	Dirty	155	This program automatically adjusts the temperature and
Auto	Clean	110	the quantity of water, the energy consumption and the program duration.
Intensive Plus 165 Suitable for heavily soiled dishes that are kep		Suitable for heavily soiled dishes that are kept waiting.	
Intensive 130 Suitable for heavily soiled dishes.		Suitable for heavily soiled dishes.	
Lightwash 117 Suitable for no		117	Suitable for normally soiled daily dishes.
Delicate		Delicate 90 Suitable for lightly soiled delicate dishes.	
Super		50	Suitable for normally soiled daily dishes with faster program.
Rinse		15	Suitable to rinse dishes that you plan to wash later.


Compatibility of		Options					
	s and Options	Half Load	Sanitize	Extra Fast	Extra Dry	Hi - Temp	Slient
	Regular	V	$\sqrt{}$	V	$\sqrt{}$	$\sqrt{}$	$\sqrt{}$
	Auto	V	√	V	V	V	√
	Intensive Plus	$\sqrt{}$	$\sqrt{}$	V	$\sqrt{}$	$\sqrt{}$	√
Programs	Intensive	$\sqrt{}$	V	$\sqrt{}$	V	$\sqrt{}$	$\sqrt{}$
ogra	Lightwash	V	V	V	V	$\sqrt{}$	√
Pre	Delicate	$\sqrt{}$	Х	$\sqrt{}$	$\sqrt{}$	Х	$\sqrt{}$
	Super	V	V	Х	√	V	Х
	Rinse	√	Х	Х	Х	Х	Х

NOTE: The program duration may change according to the amount of dishes, the water temperature, the ambient temperature and selected additional functions.


NOTE: The energy-usage label is based on the "Regular" program. This program is the most efficient in terms of its combined energy and water consumption at cleaning normally soiled dishes.

- Only use powder detergent for short programmes.
- Short programmes do not include drying.
- To assist drying, we recommend slightly opening the door after a cycle is complete.

7 THE CONTROL PANEL



- 1. On/Off Button
- 2. Program Buttons
- 3. Display
- 4. Delay Buttons
- 5. Half Load Button
- 6. Extra Dry Button
- 7. Sanitize Button
- 8. Hi-Temp Button
- 9. Extra Fast Button
- 10. Silent Button
- 11. Start/Pause Button



- 12. Rinse Aid Indicator
- 13. End Step Indicator
- 14. Sanitized Indicator
- 15. Delay Indicator
- 16. Upper Half Load Indicator
- 17. Lower Half Load Indicator
- 18. Program Time Indicator

1. On/Off Button

Turn the machine on by pressing the On/Off button.

2. Program Selection Buttons

Select a suitable program for your dishes by pressing Program buttons. For the details of the programs refer to section Program Table.

3. Display

The display shows the total time of the selected program and the remaining time during operation.

4. Delay Buttons

Press the Delay Buttons to delay the start time of a programme for 1 hour up to 24 hours. Pressing once to + button will delay the start time for 1 hour. Once you press it, display will show "1h" and display will show program duration and delay time alternately for 2 seconds. Continuing to press the button will increase the delay duration. Press the - button to decrease the delay duration. In order to start the selected program with delay, Start/Pause button(8) should be pressed and the door of the dishwasher must be closed within 4 seconds. If you turn off the machine after activating the delay time, the delayed time is cancelled

.

5. Half Load Button

Thanks to the half load function in your machine, you can shorten the durations of the programmes that you have selected and reduce the energy and water consumption by using half load electricity and water. There is half load option with 3 modes. When you press the half load button in user interface the indicator/indicators on the screen will be on according to your mode choice. If you press the button once the upper half load basket indicator will be visual, if you press the button twice the lower half load basket indicator will visual, and if you press the button 3 times, the upper half load basket indicator and lower half load basket indicator will be visual on the screen. After 4th press the button the indicators will be disappear. Also, if any of the half load option modes are selected, the half load button led will be on.

6. Extra Dry Button

Press the Extra Dry button to add extra drying steps to a program in order to obtain drier dishes. This option increases water temperature of the final rinse step and duration of the drying step. Extra Dry led will be on.

7. Sanitize Button

Sanitize function raises the water temperature in the final rinse. Sanitize led will be on.

8. Hi-Temp Button

When this option is selected, both the water temperature and the washing time are increased. Hi-Temp led will be on.

9. Extra Fast Button

Select the Extra Fast function to decrease the duration of a program, providing more economical water usage. Extra Fast led will be on.

10. Silent Button

Select the Silent function for a more sensitive and silent washing operation. This option reduces the sound pressure level of the washing. Silent led will be on.

11. Start/Pause Button

Open the door of your machine. Select the program and options. Press Start/Pause button. Close the door within 4 seconds, the program will start. If 4 seconds is exceeded and the door is closed, program will not start. The total time can change while the program is running depending on the ambient temperature where your machine is installed, temperature of the supply water and amount of the dishes. If the door is opened while the machine is running, the machine will switch to the standby mode. Press Start/Pause button and close the machine door within 4 seconds, then the program will resume.

12. Rinse Aid Indicator

When the rinse aid level is low, the rinse aid indicator turns on and you should fill the rinse aid chamber.

13. End Step Indicator

When the program is completed, end step indicator will be on and the buzzer will be activated. Buzzer sounds 5 times each at 5 minutes intervals (in 0, 5, 10 and 15th minutes) in total 4 different times at the end of the program.

14. Sanitized Indicator

If the program selected with the Sanitize option is successfully sanitized, Sanitized Indicator lights up at the end of the program. If the washing cycle is interrupted or adequate water heating cannot be achieved, the Sanitized Indicator may not light.

15. Delay Indicator

When program is started with delay, the Delay Indicator will be on.

16. Upper Half Load Indicator

If you have dishes only in the upper basket, select the half load upper basket option. If it is selected, half load upper basket indicator will illuminate.

17. Lower Half Load Indicator

If you have dishes only in the lower basket, select the half load lower basket option. If it is selected, half load lower basket indicator will illuminate.

Note: If you have dishes both of in the upper and lower basket, select the half load upper basket and half load lower basket option together. If it is selected, upper half load basket indicator and lower half load basket indicator together will illuminate.

18. Programme Time Indicator

Program duration can be monitored via Program Time Indicator.



1. Changing a Programme

Follow the steps below to change a program while in operation.
Open the door and press the Start/Pause Button (11). Choose a new program by pressing Program buttons (2). After program selection, press the Start/Pause button (11). After closing the door within 4 seconds, the newly selected program will resume the course of the old program. If 4 seconds is exceeded and the door is closed, program will not resume.

NOTE: Open the door slightly at first to stop a wash program before it is complete in order to avoid water spillage.

Cancelling a Programme

Follow the steps below if you would like to cancel a program while in operation. Open the door of your machine. The selected program will appear on the display. Press and hold the Start/Pause button (11) for 3 seconds. "0:01" will be shown on the display. Press Start/Pause button (11) and after closing the door of the machine within 4 seconds, the water discharge process will start and continue for 30 seconds. When the program is cancelled, buzzer will sound 5 times.

Switching the Machine Off

"0" will be shown on the display when the selected program is complete. Buzzer will also sound 5 times. You can then switch your machine off using the Power On/Off button. Disconnect the plug and turn off the water tap.

NOTE: Do not open the door before the program is complete.

NOTE: If the door of the machine is opened or the power is cut off while a program is in operation, the program will continue when the door is closed or the power returns.

NOTE: If the power is cut off during the drying process, the program will terminate. Your machine will be ready for a new program selection.

Menu Settings

Press Extra Dry button (6) for 3 seconds to enter menu. Water hardness setting (e.g. SL1) is seen first. Press Delay buttons (4) to surf through menu. Then, press Half Load button (5) to enter to the levels of the setting you want to change in the menu. At this time display (3) blinks and that means this setting can be changed by pressing Delay buttons (4). Set the new level with Delay buttons (4) and press Half Load button (5) to save new level. After that display (3) will light up constantly and that means this setting level is saved. You can change another setting with these steps or exit from menu by pressing Extra Dry button (6) for 3 seconds or turning off/on.

No	Setting	Options	Description
		SL1*	
		SL2	
1	Water Hard- ness	SL3	Set the water hardness.
	11033	SL4	naraness.
		SL5	
		SL6	
		r:1	
		r:2	
2	Rinse Aid	r:3	Set the amount of rinse aid.
		r:4*	
		r:5	
		b:0	Set the buzzer sound level.
3	Buzzer Sound	b:1	
3	Control	b:2	
		b:3*	
4	Start Prog-	LP0*	Set a default programme for when the app-
4	ramme	LP1	liance switched on.
		SP0	
5	Save Power Mode	SP1*	Set the Save Power Mode.
		SP2	
6	Factory	FS0*	Restore changed
6	Setting	FS1	settings to the factory settings.

^{*}Default setting

1. Water Hardness

To change the water hardness setting, follow the "4.7 Water Hardness Setting".

2. Rinse Aid

To change the rinse aid setting, follow the "4.12 Rinse Aid Setting".

3. Buzzer Sound Control

To change the buzzer sound control, follow the "Menu Settings". "b:3" level is the highest sound level. "b:0" level means all voices are off.

4. Start Programme

To change the start programme selection, follow the "Menu Settings". In "LP0" level, machine turns on with Eco program. In "LP1" level, machine turns on with last selected program and option.

5. Save Power Mode

To change the save power mode setting, follow the "Menu Settings". In "SP0" level, interior lights (if available) will always be off, the screen will turn off after 4 minutes and the machine will turn off after 15 minutes of no activity in order to save energy. In "SP1" level, interior lights will turn off after 4 minutes when the door is opened, the screen will turn off after 4 minutes and the machine will turn off after 15 minutes of no activity in order to save energy. In "SP2" level, when the machine is off position, interior lights will turn off after 4 minutes when the door is opened. When the machine is on position, interior lights

is on as long as the door stays open and machine will not turn off except by pressing On/off button.

6. Factory Setting

To change the factory setting, follow the "Menu Settings". If you change the level as "FS1" in factory setting, all settings return to default setting.

Infoled 2.1 (Model Dependent)

Infoled that is positioned on the bottom side of the dishwasher shines a light on to floor to indicate the current status of the dishwasher during washing.

LED Indicator	State of the Machine
Red, continuous	The machine is running a program.
Red, flashing	A program is cancelled.
Red, flashing rapidly	The machine has a fault. Refer to section "Automatic fault warnings and what to do".
Green, continuous	A program is finished.

8 MAINTENANCE AND CLEANING

/! WARNING: Before cleaning or carrying out maintenance, switch off the appliance, disconnect the mains plug and turn off the water tap.

Your dishwasher can only be repaired by an authorized service agent. Do not try to repair your machine unless any recommendation by this manual

WARNING: All surfaces are susceptible to scratching. Contact with unsuitable cleaning agents can alter or discolor all surfaces.

warning: Keep the floor around your dishwasher clean and dry to prevent any possible injury. We recommend to keep your dish washer clean, empty and door cracked open to allow air to circulate in case of any extended unused time.

Dishwasher door can be damaged by abrasive cleaners, scouring pads, abrasive cloths. Cleaning the machine in regular intervals prolongs the machine's service life.

Oil and lime may accumulate in the machine's washing section. In case of such accumulation; -Fill the detergent compartment without loading any dishes into the machine, select a program that runs at high temperature, and start the machine

In case of insufficiency, use special cleansing mate-rial available in the market. (Cleansing material produced special to machines by detergent produc-ers.) Cleaning the seals in the machine door,

- To clean any accumulated residues in the door seals, wipe the seals regularly by using a dampened cloth.

Cleaning the machine, Clean the filters and spray arms at least once a month.


Unplug your machine and turn off its tap before starting the cleaning.

Do not use hard materials when cleaning your machine. Wipe with a fine cleaning material and a dampened cloth.

Filters Check if any food wastes have remained on the coarse and fine filters. If any food wastes are left, remove the filters and clean them thoroughly under the water tap.

Filter

- a. Micro Filter
- b. Coarse Filter
- c. Metal/Plastic




Spray Arms

Check whether or not the holes for the upper and lower spray arms are clogged. If there is any clogging, remove the spray arms and clean them under water.

You can remove the lower spray arm by pulling it upwards, while the upper spray arm nut can be removed by turning the nut to the left.

Be sure that the nut is perfectly tightened when refitting the upper spray arm.





Cleaning The Impellers


Clean the impellers at least once a week in order for the machine operates efficiently.

Lower Impeller

Check if the holes on the lower impeller (1 are clogged. If they are clogged, remove and clean the impeller. Pull the lower impeller up to remove it (A, B.)








Upper Impeller

Check if the holes on the upper impeller 1 are clogged. If they are clogged, remove and clean the impeller. Turn its nut to left to re-move the upper impeller (A, B) Make sure that the nut is tightened well when installing the upper impeller.





9 TROUBLESHOOTING

FAULT	POSSIBLE CAUSE	TROUBLESHOOTING	
	Your Dishwasher is not plugged in.	Plug your Dishwasher in.	
	Your Dishwasher is not switched on.	Switch your Dishwasher on by pressing the On/Off button.	
The programme does	Fuse blown.	Check your indoor fuses.	
not start.	Water inlet tap is closed.	Turn on the water inlet tap.	
	Your Dishwasher door is open.	Close the Dishwasher door.	
	Water inlet hose and machine filters are clogged.	Check the water inlet hose and machine filters and make sure they are not clogged.	
	Water drain hose is clogged or twisted.	Check the drain hose, then either clean or untwist it.	
Water remains inside the machine.	The filters are clogged.	Clean the filters.	
	The programme is not finished yet.	Wait until the programme is finished.	
Machine stops during	Power failure.	Check mains power.	
washing.	Water inlet failure.	Check water tap.	
Shaking and hitting noises are heard during a wash operation. The spray arm is hitting the dishes in the lower basket.		Move or remove items blocking the spray arm.	
	Dishes placed incorrectly, sprayed water not reaching affected dishes.	Do not overload baskets.	
	Dishes leaning each another.	Place dishes as instructed in the section on loading your dishwasher.	
Partial food wastes remain on the dishes.	Not enough detergent used.	Use the correct amount of detergent, as instructed in the programme table.	
	Wrong wash programme selected.	Use the information in the programme table to select the most appropriate programme.	
	Spray arms clogged with food waste.	Clean the holes in the spray arms with thin objects.	
	Filters or water drain pump clogged or filter misplaced.	Check the drain hose and filters are correctly fitted.	

FAULT	POSSIBLE CAUSE	TROUBLESHOOTING	
Whitish stains remains on dishes.	Not enough detergent used.	Use the correct amount of detergent, as instructed in the programme table.	
	Drying option is not selected.	Select a programme with a drying option.	
Dishes do not dry.	Rinse aid dosage set too low.	Increase rinse aid dosage setting.	
Rust stains form on the	Stainless-steel quality of the dishes is insufficient.	Use only dishwasher-proof sets.	
dishes.	A poor mains grounding.	Consult a qualified electrician immediately.	
Detergent remains in the detergent compartment.	Detergent was added when the detergent compartment was wet.	Make sure detergent compartment is dry before use.	

AUTOMATIC FAULT WARNINGS AND WHAT TO DO

TROUBLE CODE	POSSIBLE FAULT	WHAT TO DO
		Make sure the water inlet tap is open and water is flowing.
FF	Water inlet system failure	Separate the inlet hose from the tap and clean the filter of the hose.
		Contact for service if the error continues.
F5	Pressure system failure	Contact for service.
F3	Continuous water input	Close the tap and contact for service.
		Water discharge hose and filters may be clogged.
F2	Inability to discharge water	Cancel the program.
		If the error continues, contact for service.
F8	Heater error	Contact for service.
F4	0	Unplug the machine and close the tap.
F1	Overflow	Contact for service.
F7	Overheating	Contact for service.
F9	Divisor position error	Contact for service.
F6	Faulty heater sensor	Contact for service.
НІ	High voltage failure	Contact for service.
LO	Low voltage failure	Contact for service.