



1.6 Cu.Ft. Over the Range Microwave

MODEL NUMBER SERIES:
FOTR3007-30 / FOTR3007-30BLK / FOTR3007-30WHT

User's Manual

Read these instructions carefully before using your appliance, and keep it carefully.
If you follow the instructions, your appliance will provide you with many years of good service.
SAVE THESE INSTRUCTIONS CAREFULLY

Contents

Customer Care	2
SAFETY INFORMATION	3
Precautions to avoid possible exposure to excessive microwave energy:	3
IMPORTANT SAFETY INSTRUCTIONS	3
Unpacking instructions	4
Grounding instructions	4
Cookware and cooking materials	6
Materials you can use	6
Materials to be avoided	6
Features	7
Package contents	7
Microwave	7
Control panel	8
Setting up your microwave	9
Installing the turntable	9
Using your microwave	10
Cooking in your microwave	10
Setting the clock	10
Using the kitchen timer	10
Turning sound on and off	10
Cooking quickly	10
Cooking complete reminders	10
Cooking with the auto menu	11
Checking the time and power level while cooking	12
Using the light	12
Using the vent fan	12
Using the child lock	12
Using the turntable	12
Cleaning and maintaining your microwave	12
Cleaning the outside of your microwave	12
Cleaning the inside of your microwave	12
Cleaning and replacing the filters	13
Changing the LED bulbs	15
Troubleshooting	16
Obtaining replacement parts	16
Specifications	16
Legal notices	17

Customer Care

Thank you for purchasing a Frono product. Please read the entire instruction manual before operating your new appliance for the first time. Whether you are an occasional user or an expert, it will be beneficial to familiarize yourself with the safety practices, features, operation and care recommendations of your appliance.

Both the model and serial number are listed inside the product. For warranty purposes, you will also need the date of purchase .

Product Information

Model Number : _____

Serial Number : _____

Date of Purchase : _____

Purchase Address And Phone : _____

Service Information

Use these numbers in any correspondence or services calls concerning your product.

If you received a damaged product, immediately contact Forno.

To save time and money, before you call for serviced, check the troubleshooting guide. It listed the causes of minor operation problems that you can correct yourself.



“Need some quick help? Simply scan the qr code and get access to our fast support form. We’re always here to assist you with any questions or concerns you may have. So, don’t hesitate to reach out!”

Services in Canada and Untied States

Keep the instruction manual handy to answer your questions. If you don’t understand something or need more assistance, please visit our website for fast support. Please provide us your name, number, address, serial number of the product that troubleshooting, proof of purchase, and a short description of the issue. A customer service representative will contact you as soon as possible. All warranty work needs to be authorized by FORNO customer service. All our authorized service providers are carefully selected and rigorously trained by us.

SAFETY INFORMATION

Precautions to avoid possible exposure to excessive microwave energy:

- 1 Do not attempt to operate this microwave with the door open because this can result in harmful exposure to microwave energy. It is important not to defeat or tamper with the safety interlocks.
- 2 Do not place any object between your microwave front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- 3 Do not operate your microwave if it is damaged. It is particularly important that the microwave door closes properly and that there is no damage to the:
 - (a) DOOR (bent)
 - (b) HINGES and LATCHES (broken or loosened)
 - (c) DOOR SEALS and SEALING SURFACES
- 4 Your microwave should not be adjusted or repaired by anyone except properly qualified service personnel.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of burns, electric shock, fire, injury to persons, or exposure to excessive microwave energy when using your microwave, follow these basic safety precautions.

- 1 Read all instructions before using the microwave.
- 2 Read and follow: Precautions to avoid possible exposure to excessive microwave energy: on page 3.
- 3 This appliance must be grounded. Connect only to a properly grounded outlet. See Grounding instructions on page 4.
- 4 Install or locate this appliance only in accordance with the provided installation instructions.
- 5 Some products such as whole eggs and sealed containers (closed glass jars, for example) are able to explode and should not be heated in this microwave.
- 6 Use this appliance only for its intended use as described in this manual. Do not use corrosive chemicals or vapors in this appliance. This type of microwave is specifically designed to heat, cook, or dry food. It is not designed for industrial or laboratory use.
- 7 HOT CONTENTS CAN CAUSE SEVERE BURNS. DO NOT ALLOW CHILDREN TO USE THE MICROWAVE. Use caution when removing hot items.
- 8 To reduce the risk of fire in the microwave cavity:
 - a) Do not overcook food. Carefully monitor the appliance when paper, plastic, or other combustible materials are placed inside the microwave to facilitate cooking.
 - b) Remove wire twist-ties from paper or plastic bags before placing the bag in the microwave.
 - c) If materials inside the microwave should ignite, keep the microwave door closed, turn the microwave off, and disconnect the power cord or shut off power at the fuse or circuit breaker panel.
 - d) Do not use the cavity for storage purposes. Do not leave paper products, cooking utensils, or food in the cavity when not in use.
- 9 Liquids, such as water, coffee, or tea can be overheated beyond the boiling point without appearing to be boiling. Visible bubbling or boiling when the container is removed from your microwave is not always present. THIS COULD RESULT IN VERY HOT LIQUIDS SUDDENLY BOILING OVER WHEN THE CONTAINER IS DISTURBED OR A SPOON OR OTHER UTENSIL IS INSERTED INTO THE LIQUID.
 - a) Do not overheat the liquid.
 - b) Stir the liquid both before and halfway through heating it.
 - c) Do not use straight-sided containers with narrow necks.
 - d) After heating, allow the container to stand in your microwave for a short time before removing the container.
 - e) Use extreme care when inserting a spoon or other utensil into the container.
- 10 Do not heat oil or fat for deep-frying. It is difficult to control the temperature of oil in your microwave.
- 11 Pierce foods with heavy skins such as potatoes, whole squash, apples, and chestnuts before cooking.
- 12 The contents of feeding bottles and baby jars should be stirred or shaken and the temperature should be checked before serving in order to avoid burns.
- 13 Cooking utensils may become hot because of heat transferred from the heated food. Potholders may be needed to handle the utensil.
- 14 Do not cover or block any openings on the appliance.

- 15 Do not store or use this appliance outdoors. Do not use this product near water, for example, near a kitchen sink, in a wet basement, near a swimming pool, or similar locations.
- 16 Do not operate this appliance if it has a damaged cord or a plug, if it is not working properly, or if it has been damaged or dropped.
- 17 Do not immerse the cord or plug in water. Keep the cord away from heated surfaces. Do not let the cord hang over the edge of a table or counter.
- 18 Use only thermometers which are specifically designed for use in microwaves.
- 19 Be certain the glass tray and roller rings are in place when you operate the microwave.
- 20 This appliance should be serviced only by qualified service personnel. Contact the nearest authorized service facility for examination, repair, or adjustment.
- 21 When cleaning surfaces of the door and microwave that come together on closing the door, use only mild, nonabrasive soaps, or detergents applied with a sponge or soft cloth.
- 22 VENTILATING HOODS:
 - a) clean ventilating hoods frequently-grease should not be allowed to accumulate on the hood or filter.
 - b) When cooking foods under the hood, turn the fan on.
- 23 Use care when cleaning the vent-hood filter. Corrosive cleaning agents, such as lye-based oven cleaners, may damage the filter.
- 24 To reduce the risk of fire and electric shock, install only above electric cooking equipment. If the over-the-cooktop microwave is intended to be used with either a gas or electric range, the following words or the equivalent shall be included: Suitable for use above both gas and electric cooking equipment.

Unpacking instructions

Carefully remove your microwave from the box. Save the box as it may make installation easier.

- 1 Remove all packing materials from inside the microwave cavity. However, DO NOT REMOVE THE WAVEGUIDE COVER, which is located on the right side in the oven cavity. Make sure that you have all items from the Package contents on page 7. Read and save the instructions.
- 2 Remove the feature sticker from the outside of the door, if there is one.
- 3 Check the microwave for any damage, such as a misaligned or bent door, damaged door seals and sealing surfaces, broken or loose door hinges and latches, and dents inside the cavity or on the door. If there is any damage, do not operate the microwave and contact your dealer.

See the *Installation Guide* for more information.

Grounding instructions

This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

WARNING: Improper use of the grounding plug can result in a risk of electric shock. Consult a qualified electrician or serviceman if the grounding instructions are not completely understood or if doubt exists as to whether the appliance is properly grounded.

Electrical requirements

The electrical requirements are a 120VAC, 60Hz, AC only. It is recommended that a separate circuit serving only the microwave be provided. The microwave is equipped with a three-prong grounding plug. It must be plugged into a wall receptacle that is properly installed and grounded.

Power Supply Cord

- 1 A short power supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
- 2 Longer cord sets or extension cords are available and may be used if care is exercised in their use.
- 3 If a long cord or extension cord is used:
 - a) The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance.
 - b) The extension cord must be a grounding-type three-wire cord, and the longer cord should be arranged so that it will not drape over the counter top or table top where it can be pulled on by children or tripped over unintentionally.
 - c) If it is necessary to use an extension cord, use only a three-wire extension cord that has a three-blade grounding plug, and a three-slot receptacle that will accept the plug on the appliance. The marked rating of the extension cord shall be equal to or greater than the electrical rating of the appliance.

Notes:

- If you have any questions about the grounding or electrical instructions, consult a qualified electrician or service person.
- We does not accept any liability for damage to the microwave or personal injury resulting from failure to observe the electrical connection procedures.

Radio or TV interference

Should there be any interference caused by your microwave to your radio or TV, make sure that your microwave is on a different circuit. Relocate the radio or TV as far away from the microwave as feasible or check the position and signal of the receiving antenna.

SAVE THESE INSTRUCTIONS

Cookware and cooking materials

WARNING: Personal Injury Hazard

Tightly-closed containers could explode. Closed containers should be opened and plastic pouches should be pierced before cooking.

Cookware and other materials must fit on the turntable. Always use oven mitts or pot holders because cookware may become hot.

Refer to the **Materials you can use** and **Materials to be avoided** tables as a guide, then test before using.

Cookware and Materials Test:

- 1 Fill a microwave-safe container with 1 cup (236 ml) of cold water, along with the cookware or materials in question.
- 2 Cook on maximum power for one minute. **Do not exceed one minute cooking time.**
- 3 Carefully feel the cookware or material. If the empty cookware or material is warm, do not use it for microwave cooking.

Materials you can use

MATERIAL	REMARKS
Aluminum foil	Use as shielding only. Small, smooth pieces can be used to cover thin parts of meat or poultry to prevent overcooking. Arcing can occur if the foil is wrinkled or too close to microwave walls. The foil should be at least 1 in. (2.5 cm) away from microwave walls.
Browning dish	Follow the manufacturer's instructions. The bottom of the browning dish must be at least 3/16 in. (5 mm) above the turntable. Incorrect usage may cause the turntable to break.
Dinnerware	Use microwave-safe only. Follow the manufacturer's instructions. Do not use cracked or chipped dishes.
Glass jars	Always remove the lid. Use only to heat food until just warm. Most glass jars are not heat resistant and may break.
Glassware	Use heat-resistant oven glassware only. Make sure there is no metallic trim. Do not use cracked or chipped dishes.
Oven cooking bags	Follow the manufacturer's instructions. Do not close with a metal tie. Make slits to allow steam to escape.
Paper plates and cups	Use for short-term cooking/warming only. Do not leave the microwave unattended while cooking.
Paper towels	Use to cover food for reheating and absorbing fat. Use with supervision for short-term cooking only.
Parchment paper	Use as a cover to prevent splattering or a wrap for steaming.
Plastic	Use only if labeled "Microwave Safe." Follow the manufacturer's instructions. Some plastic containers soften as the food inside gets hot. "Boiling bags" and tightly closed plastic bags should be slit, pierced, or vented, as indicated on the package.
Plastic wrap	Use microwave-safe only. Use to cover food during cooking to retain moisture. Do not allow plastic wrap to touch food.
Thermometers	Use microwave-safe only (such as meat and candy thermometers).
Wax paper	Use as a cover to prevent splattering and retain moisture.

Materials to be avoided

MATERIAL	REMARKS
Aluminum tray	May cause arcing. Use a microwave-safe dish instead.
Food carton with metal handle	May cause arcing. Use a microwave-safe dish instead.
Metal or metal trimmed utensils	Metal shields the food from microwave energy. The metal trim may cause arcing.
Metal twist ties	May cause arcing and could cause a fire in the microwave.
Paper bags	May cause a fire in the microwave.
Plastic foam	Plastic foam may melt or contaminate the liquid inside when exposed to high temperature.
Wood	Wood will dry out when used in your microwave and may split or crack.


Features

- 9 auto-cook settings
- 10 variable power levels
- 1,000 watts of power
- 30-second express cooking
- 2-stage cooking available
- Exhaust fan with two speeds
- Hidden vent
- Task lighting
- Child lock
- 13.6-inch glass turntable

Package contents


- 1.6 cu. ft. over-the-range microwave
- Turntable (with ring)
- Installation hardware
- Grease filter
- Exhaust damper
- *Installation Guide*
- *User Guide*

Microwave



#	ITEM	DESCRIPTION
1	Safety interlock system	Prevents your microwave from operating when the door is open.
2	Top vent outlet	Vents hot air from inside your microwave. Do not block.
3	Glass turntable	Allows food to cook more evenly.
4	Turntable ring assembly	Allows the turntable to rotate to cook food more evenly.
5	Waveguide cover	Covers the waveguide. DO NOT REMOVE.
6	Control panel	Use to set cooking times and enter other information as needed.
7	Turntable shaft	Rotates the turntable assembly.

Control panel




#	ITEM	DESCRIPTION
1	Display	In standby mode, displays the time. In cooking mode, displays cooking time, weight, and other information.
2	Auto menu	Press one of these buttons to automatically cook the item indicated. See Cooking with the auto menu on page 10.
3	*Clock	Press and hold for three seconds, then enter the time. See Setting the clock on page 10.
4	Number pad and EXPRESS buttons	Press to enter cook time, defrost time, clock time, and other information. EXPRESS - press 1, 2, or 3 to quickly cook for that many minutes, at 100% power.
5	*Turntable On/Off	Press and hold this button for three seconds to turn the turntable on or off. See Using the turntable on page 12.
6	Start	In standby mode, or after you enter the cooking time, press this button to begin cooking.
7	 (vent)	Press to turn on your vent fan. Press repeatedly to select the fan speed. You can select High, Low, or Off. See Using the vent fan on page 12.
8	Defrost	Press once, enter the time you want to defrost, then press Start . See Defrost on page 11.
9	Power Level	To set the power level of your microwave, press Power Level , then enter the power level you want (0-10). See Cooking in your microwave on page 10.
10	Timer On/Off	Press once, then enter the time you want to count down. See Using the kitchen timer on page 10.
11	Cook time	Press once, then enter the time you want your food to cook.
12	*  (lock)	Press and hold for three seconds to lock or unlock the control panel.
13	Stop/Cancel	Press to stop the cooking process. Press again to cancel the cooking operation.
14	+30 Sec.	Press once to start a 30 second cooking cycle or to add 30 seconds to the current cooking time. Press repeatedly to add 30 second increments.
15	 (light)	Press to turn the light under your microwave on or off. See Using the light on page 12.
16	Sound	All sounds are turned on by default. The display shows "on" when you press the Sound button the first time. Press the Sound button again to turn off the keypad beep sound. The display shows "oFF1". Press the Sound button a third time to turn off all sounds. The display shows "oFF2". Press the Sound button a fourth time to turn all sounds back on. The display shows "on".

Setting up your microwave

See the *Installation Guide* (included in your box) to install and set up your microwave.

Installing the turntable



Notes:

- Never place the glass tray upside down. The glass tray should never be restricted.
- Both the glass tray and turntable ring must always be used during cooking.
- Always place all food and containers of food on the glass tray for cooking.
- If the glass tray or turntable ring cracks or breaks, contact your nearest authorized service center.

- 1** Place the turntable ring in the round depression in the bottom of your microwave so that it turns freely.
- 2** Place the glass turntable (flat side up) on the turntable ring so that the hub engages the turntable shaft in the bottom of the microwave. The glass turntable should not turn freely when it is correctly installed.

Using your microwave

Cooking in your microwave

- 1 Press **Cook Time**, then use the number pad to enter the cooking time that you want.

Note: For example, to enter 3 minutes and 15 seconds, press **3**, **1**, and then **5**.

- 2 Press **Power Level**, then enter the power level that you want (0-10).

LEVEL	10	9	8	7	6	5	4	3	2	1	0
Power	100%	90%	80%	70%	60%	50%	40%	30%	20%	10%	0%
Display	P-H1	P-90	P-80	P-70	P-60	P-50	P-40	P-30	P-20	P-10	P-0

Notes:

- You can check the power level during cooking by pressing **Power Level**. To change it, enter a new power level (0–10).
- If “P-0” is selected, the fan turns on but microwave cooking power will be at 0%. You can use this level to remove an odor in your microwave.

- 3 Press **Start** to begin heating.

OR

For two-stage cooking, repeat steps 1-2 to program the second stage.

Notes on two-stage cooking:

- Two-stage cooking lets you program two cook times and power levels at the same time.
- The first time/power level entered is the first stage and the second time/power level entered is the second stage.
- Two stage cooking does not show up on the display, but the total cook time is displayed.
- Two-stage cooking is useful to defrost and then cook, or cook at full power and then partial power.

Setting the clock

- 1 In standby mode, press and hold ***Clock** for three seconds. The display will flash.
- 2 Use the number pad to enter the current time (1:00–12:59), then press **Start** to confirm the setting. If your microwave beeps three times, the numbers entered are valid.

Using the kitchen timer

- 1 In standby mode, press **Timer On/Off**. The display shows “: 0” and “TIMER”.
- 2 Use the number pad to enter the time (the maximum time is 99 minutes and 99 seconds), then press **Start** to start the timer.
When the timer reaches 0, your microwave beeps three times. If you do not stop the timer, your microwave will beep three times every five seconds to remind you. Your microwave will repeat this reminder a maximum of six times.

Turning sound on and off

- 1 Press **Sound** to turn off the beep sounds when panel buttons are touched. “OFF 1” appears on the display momentarily.
- 2 Press **Sound** again to turn off all beep sounds including end of cycle and timer alerts. “OFF 2” appears on the display momentarily.
- 3 Press **Sound** again to turn on all sounds. “on” appears on the display momentarily.

Cooking quickly

- Press **+30 Sec.** to instantly cook something at 100% power for 30 seconds.
- To increase the time in 30 second increments (except Auto Cook), press **+30 Sec.** repeatedly.
- Press the **1**, **2**, or **3** (express number) keys to immediately start fast cooking for the corresponding number of minutes at 100% power.

Cooking complete reminders

At the end of the cooking cycle, your microwave stops running and beeps. The display will show “End” until you remove the food or press **Stop**. If you do not remove the food, your microwave will beep twice to remind you. Your microwave will repeat this reminder three times, once every three minutes.

Cooking with the auto menu

Defrost

- 1 Press **Defrost**. The display shows "00:00" and "Def."
- 2 Use the number pad to enter the defrosting time you want. The time entered must be between 00:01 and 99:99.
- 3 Press **Start** to start defrosting. The remaining cooking time is displayed.

Note: Three rapid beeps will sound at the halfway point to prompt you to turn the food over.

Tips on defrosting

Defrosting steak, pork, chicken, or fish:

- 1 Remove the meat from your freezer. Defrost times depend on the approximate weight of your food, so check the label or weigh your item.
- 2 Place the meat in a microwave safe container (see [Cookware and cooking materials](#) on page 6).
- 3 Press **Defrost** on your microwave, then set the cooking timer to defrost for 8 – 10 minutes per pound. The thawing time for fish or other seafood can vary, so check the packaging for more information.
- 4 To ensure even thawing, stop the timer every few minutes to turn or flip the meat.
- 5 When finished, remove the meat and cook immediately.

Defrosting fruits and vegetables:

- 1 Remove the fruit or vegetables from your freezer.
- 2 Determine the weight of the produce.
- 3 Place the produce in a microwave safe container (see [Cookware and cooking materials](#) on page 6).
- 4 Press **Defrost** on your microwave, then set the cooking timer to defrost for two minutes.
- 5 After two minutes, separate the pieces. For leafy vegetables like cooked spinach, pull the block apart into smaller pieces.
- 6 Continue to defrost for one minute for every four ounces of produce. Check and stir occasionally, until completely thawed.
- 7 When finished, move to your stove top and cook immediately.

Potato

- 1 Press **Potato**. The display shows "1".
- 2 Use the number pad to enter the number of potatoes, 1 through 4, as necessary.
- 3 Press **Start**.

Veggies

- 1 Press **Veggies** once for fresh vegetables and twice for frozen vegetables. The display shows "FrSH" or "FroZ."
- 2 Press the number pad to enter the amount of vegetables (cups) to cook.

FOOD	DISPLAY	AMOUNT	NUMBER PAD	TOTAL TIME
Fresh vegetables	FrSH	1 cup	1	3:20
		2 cups	2	5:00
		3 cups	3	7:00
		4 cups	4	8:40
Frozen vegetables	FroZ	1 cup	1	4:30
		2 cups	2	7:30
		3 cups	3	10:30
		4 cups	4	13:30

- 3 Press **Start**.

Popcorn

- 1 Press **Popcorn**. The display shows "3.0" and "OZ."
- 2 Use the number pad to enter the amount of popcorn:
 - Press **1** for 3.0 oz.
 - Press **2** for 3.3 oz.
 - Press **3** for 1.5 oz.
 - Press **4** for 2.7 oz.
 - Press **5** for 2.8 oz.
- 3 Press **Start**

Beverage

- 1 Press **Beverage**.
- 2 Use the number pad (1-3) to enter the amount from 1-3 cups (8.0 oz./cup).
- 3 Press **Start**.

Checking the time and power level while cooking

- To check the power level while cooking a meal, press **Power Level**. The display shows the power level being used for three seconds, then returns to the cooking time remaining.

Using the light

- Press  (light) to turn the light underneath your microwave on or off.

Using the vent fan

Your microwave's vent fan works as a range hood to filter out smoke and other odors while cooking.

- Press  (vent) repeatedly to cycle between high speed, low speed, or off.

Note: You can choose the vent speed while cooking in your microwave.

Using the child lock

- To lock the control panel buttons, press and hold  (lock) for three seconds. Your microwave beeps and a lock indicator appears on the display.
- To unlock the control panel buttons, press and hold  (lock) until the lock indicator disappears (about three seconds).

Using the turntable

- To turn off the turntable, press and hold ***Turntable On/Off** for about three seconds while cooking your food. The display shows "off" for two seconds.
- To turn the turntable back on after turning it off, press and hold ***Turntable On/Off** for about three seconds while cooking your food. The display shows "on" for two seconds.

Note: Your microwave defaults to having the turntable on.

Cleaning and maintaining your microwave

Cleaning the outside of your microwave

Exterior

The outside surface is precoated steel and plastic. Clean the outside with mild soap and water, then rinse and dry with a soft cloth. Do not use any type of household or abrasive cleaner.

Door

Wipe the window on both sides with a damp cloth to remove any spills or spatters. Metal parts will be easier to maintain if wiped frequently with a damp cloth. Avoid the use of spray and other harsh cleaners as they may stain, streak, or dull the door surface.

Control panel

If the control panel is dirty, open the microwave door before cleaning. Wipe the panel with a cloth dampened slightly with water only. Dry with a soft cloth. Do not scrub or use any sort of chemical cleaners. Close the door and press **Stop** to clear any buttons you may have pressed.

Cleaning the inside of your microwave

Interior

Wipe with a soft cloth and warm water. Do not use abrasive or harsh cleaners or scouring pads. For baked-on food, use baking soda or a mild soap, then rinse thoroughly with hot water.

Waveguide cover

The waveguide cover is located on the right side of the microwave cavity. It is made from mica and requires special care. Keep the waveguide cover clean to assure good microwave performance. Carefully wipe with a damp cloth any food spatters from the surface of the cover immediately after they occur. Built-up splashes may overheat and cause smoke or possibly catch fire. **DO NOT REMOVE THE WAVEGUIDE COVER.**

Removing odors

Occasionally, a cooking odor may remain in your microwave. To remove, combine one cup water, the grated peel and juice of one lemon, and several whole cloves in a two-cup glass measuring cup. Boil for several minutes using 100% power, then let it cool in your microwave. Wipe the interior with a soft cloth.

Turntable and turntable support

Remove the turntable and turntable support and wash them in mild, sudsy water. For stubborn stains, use a mild cleanser and non-abrasive scouring sponge. You can also wash them in the top rack of a dishwasher.

The turntable motor shaft is not sealed, so excess water or spills should be wiped up immediately.

Cleaning and replacing the filters


Cleaning the grease filters

Clean the filter at least once a month. Never use the fan or microwave without the filters in place.

- 1 Pull down slightly on the tab toward the front of your microwave to remove the filter. Repeat for the other filter.
- 2 Soak the filters in a sink or dish pan filled with hot water and detergent.

CAUTION: DO NOT use ammonia or other alkali cleaning products. They will react with the filter material and darken it.


- 3 Agitate and scrub the filters with a brush to remove embedded dirt.
- 4 Rinse thoroughly and shake dry.
- 5 Replace by fitting the filters back into the opening.



Replacing the charcoal filter


A charcoal filter is used for a nonvented, recirculated installation. The filter should be changed every 6 to 12 months depending on use.

- 1 Disconnect power to your microwave at the circuit breaker or by unplugging it.
- 2 Remove the vent grille mounting screws from the top of the vent grille, then push down on the tabs at each end of the vent grille to disengage it.




- 3 Pull the vent grille away from the unit.


- 4** Remove the charcoal filter by pushing it inwards, then turn and pull it away from the unit.



- 5** Slide the new filter into the top of the unit, then press the bottom of the filter into place.



- 6** Carefully push the vent grille back into place and replace the vent grille mounting screws.




Changing the LED bulbs

Countertop light (exterior)


- 1 Disconnect power to your microwave at the circuit breaker or by unplugging it.
- 2 Remove the screws holding the base plate in place, then swing the base plate down to access the LED bulb.

CAUTION: The light cover may become very hot. Do not touch the glass when the light is on.



- 3 Remove the old light bulb, then replace with a new bulb.

CAUTION: Do not use a bulb higher than 30 watts.



- 4 Swing the base plate back into place and secure it with the screws.

Troubleshooting

If you have a problem with your microwave, review the following chart for a possible solution. If your microwave still does not work properly, contact the nearest authorized service center.

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
My microwave will not start	The electrical cord is not plugged in.	Plug in the electrical cord.
	The door is open.	Close the door and try again.
	The wrong operation is set.	Check the instructions and try again.
	The circuit breaker may have tripped.	Check the circuit breaker and reset if needed.
Arcing or sparking in my microwave	You are attempting to use incorrect materials in your microwave.	Use only microwave-safe materials.
	You are attempting to use your microwave when it's empty.	Do not operate your microwave when it's empty.
	Spilled food remains in your microwave.	Clean your microwave with a wet towel.
Unevenly cooked foods	You are attempting to use incorrect materials in your microwave.	Use only microwave-safe materials.
	The food is not defrosted completely.	Defrost the food completely before attempting to cook it.
	The cooking time or power level is not adequate to cook the food.	Use the correct cooking time and power level.
	The food is not turned or stirred.	Turn or stir the food.
Overcooked foods	The cooking time is too long or power level is too high.	Use the correct cooking time and power level.
Undercooked foods	You are attempting to use incorrect materials in your microwave.	Use only microwave-safe materials.
	The food is not defrosted completely.	Defrost the food completely before attempting to cook it.
	The cooking time or power level is not adequate to cook the food.	Use the correct cooking time and power level.
	The microwave ventilation ports are blocked or restricted.	Make sure that the ventilation ports are not blocked or restricted.
Improper defrosting	You are attempting to use incorrect materials in your microwave.	Use only microwave-safe materials.
	The cooking time or power level is not adequate to cook the food.	Use the correct cooking time and power level.
	The food is not turned or stirred.	Turn or stir the food.

Specifications

Model	FOTR3007-30 / FOTR3007-30BLK / FOTR3007-30WHT
Rated voltage	120VAC, 60Hz
Rated input power	1,500W
Rated output power	1,000W

Legal notices

FCC statement

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



POUR
SERVICE RAPIDE
COURRIEL À **INFO@FORNO.CA** 

Service client : Appelez le 1-866-231-8893 ou envoyez un courriel à : info@forno.ca