

CROWN VERITY

Infinite Switch and Hardware Kit

- 1.0 Apply the provided clear stick to the front face of the hotwell.
 - 1.1 Align the center circle on the sticker with the same diameter hole cut-out on the hotwell face.
 - 1.2 There are two dark circles on the sticker. Align these horizontally on the front face.
- 2.0 With a 3/16" drill bit, drill out the two (2) black dots on the sticker. You can use an oversized drill bit on the drilled hole to clear the burrs.
- 3.0 Remove the clear sticker from the face.
- 4.0 Insert the Infinite Switch from the back of the hotwell face. Feed the stem of the infinite switch through the large central cut-out.
- 5.0 Use two (2) #8-32 x 3/16" screws to fasten the switch to the hotwell face. The screws will align with the threaded holes on the face of the Infinite Switch, on either side of the central stem. Tighten the two (2) screws into place with a Phillips screwdriver. Note: Top side of the Infinite Switch is indicated by the flat face of the stem.

