




COMMERCIAL ELECTRIC DRYER

MODELS:

CESP2978JQ0 (White)


CONTROL PANEL AND SEPARATOR PARTS



CONTROL PANEL AND SEPARATOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11651084	Facia	12	W10139046	Nut	26	279393	Screw Kit, Terminal Block
2	W10386302	Screw	13	W10133285	Transformer 120Vac To 22.5Vac	27	W11498818	Instructions, Installation (Card Reader)
3	W10137769	Cover, Card Reader	14	W10827406	Relay, Motor	28	W10239515	Harness, Card Reader
4	W10145157	Retainer, Facia Cover	15	8533971	Screw	29	W10143462	Screw
5	3400618	Screw	16	W11223375	Assembly, Lock	30	W10163036	Bezel
6	W10133268	Cover, Display	17	W10913660	Cam, Locking	31	W10807485	Harness, Collar (Includes Motor Relay)
7	W10657185	Plate, Control Mounting	18	W10160652	Bracket-Switch	32	W10773242	Screw
8	W10140652	Screw	19	W10447152	Switch, Service Access	33	W10769481	Jumper, Coin Box
9	W11582595	Control Board	20	3400408	Screw	34	W10111027	Jumper, Transformer
10	W11455510	Collar Not Illustrated	21	3397659	Block, Terminal	35	W10807493	Jumper, Lower to Collar
	337686	Screw Collar to Cabinet Flange	22	3400000	Screw	36	W10155270	Cable Tie
	3400500	Bolt Collar to Lower Cabinet	23	W10850065	Cover, Terminal Block			
			24	3390814	Screw			
			25	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)			
11	W10133514	Standoff, Circuit Board						


LOWER CABINET AND FRONT PANEL PARTS



LOWER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts (Located Behind Toe Panel)	16	3388229	Retainer	35		Plug, Hinge
	W11647901	Installation Instructions	17	98997	Clip		W10191265	White
	W11651038	Tech Sheet	18	3390735	Seal, Door	36		Panel, Front
	W11463414	Installation Instructions, Card Reader	19	W10291934	Clip		W10192882	White
2	3391915	Screw	20	W10807486	Harness, Upper/Lower	37	696144	Strike, Door
3	3390663	Screw	21		Hinge & Pin Assembly	38	3387242	Seal, Front Panel
4	3391846	Clip, Front Panel		W10279703	Silver	39	3392538	Assembly, Door Catch
5	W10131172	Belt, Drive	22	8066134	Switch Assembly	40		Panel, Toe
6	697773	Screw	23	3394881	Switch, Belt		697215	White
7		Cabinet	24	8066120	Lever, Belt Switch	41	W10237959	Switch, Door
	W11161907	White	25	98129	Screw	42	W10322546	Door, Front
8	3392100	Foot, Dryer	26	W10167612	Wire, Belt Switch	43	W10323061	Door, Rear
9	660658	Clamp, Motor	27	3398948	Wire, Jumper (Broken Belt Switch)	44	W11378153	Cover, Terminal
10	W10446781	Spring, Idler	28	W10396031	Motor	45	98139	Screw
11	3389420	Screw	29	3394341	Pulley, Motor	46	345670	Lock Top
12	W10116360	Handle, Door	30	3393657	Restrainer, Belt			DRYER EXHAUST KIT NOT INCLUDED
13	W10344193	Pulley-Idler Assembly	31	8283298	Jumper, Door Switch		W10470674	Kit, 4-Way Venting
14	342055	Screw	32	3387118	Bracket, Motor			
15	W11325273	Boot, Foot	33	W10576519	Seal, Deflector			
			34	693152	Bumper			


UPPER CABINET AND FRONT PANEL PARTS



UPPER CABINET AND FRONT PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3390663	Screw	19	W10291934	Clip	38	8283298	Jumper, Door Switch
2	3391915	Screw	20		Hinge & Pin Assembly	39	3389233	Bushing
3		Plug, Hinge		W10279703	Silver	40	W10117347	Cotter Pin
	W10191265	White	21	8066134	Switch Assembly	41	W10237959	Switch, Door
4	W10323061	Door, Rear	22	3394881	Switch, Belt	42		Panel, Front
5	W10322546	Door, Front	23	8066120	Lever, Belt Switch		W10192882	White
6	697773	Screw	24	98129	Screw	43	696144	Strike, Door
7		Cabinet	25	W10167612	Wire, Belt Switch	44	3387242	Seal, Front Panel
	W11161907	White	26	3398948	Wire, Jumper (Broken Belt Switch)	45	342055	Screw
8	W10576519	Seal, Deflector	27	W10396031	Motor	46	3388229	Retainer
9	660658	Clamp, Motor	28	3393657	Restrainer, Belt	47	3392100	Foot, Dryer
10	W10446781	Spring, Idler	29	3394341	Pulley, Motor	48	W11378153	Cover, Terminal
11	3389420	Screw	30	W10131172	Belt, Drive	49	98139	Screw
12		Top	31	3390735	Seal, Door	50	W10879744	Screw
	3389351	White	32	3387118	Bracket, Motor			DRYER EXHAUST KIT NOT INCLUDED
13	W10344193	Pulley-Idler Assembly	33	693152	Bumper		W10470674	Kit, 4-Way Venting
14		Panel, Toe	34	W10807486	Harness, Upper/Lower			
	697215	White	35	3390647	Screw			
15	W10116360	Handle, Door	36	3979115	Bracket, Angle			
16	98997	Clip	37	3400523	Bolt, Security			
17	3391846	Clip, Front Panel						
18	3392538	Assembly, Door Catch						

UPPER AND LOWER BULKHEAD PARTS



UPPER AND LOWER BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11104018	Assembly, Air Duct	17	8066086	Plug, Drum Hole	35	W10193019	Thermostat, Electronic (155F)
2	8533971	Screw	18	W10521118	Seal, Drum	36	693995	Screw
3	W11162455	Bulkhead, Rear	19	W10692558	Grill, Outlet	37	8066224	Pipe, Exhaust
4	3390647	Screw	20	3387230	Screw	38	8572105	Clip, Exhaust
5	8578825	Bracket, Drum Light	21	695240	Screw	39	W10891205	Assembly, Weld Heater Box
6	3402841	Lens, Drum Light	22	W10685669	Assembly, Outlet Housing	40	279973	Kit, Thermal Cut-Off (Includes Thermostat)
7	W10001120	Nut, Hex (Left Hand Thread)	23	W10049370	Screen, Lint	41	3391914	Thermostat HL-295/215
8	3387459	Washer	24	697557	Bulkhead, Front	42	90767	Screw
9	W10512946	Washer, Tri Ring	25	3357011	Screw	43	8066099	Bracket, Heater Box
10	W10359271	Shaft, Drum Roller - Right Hand Thread	26	697814	Seal, Drum Front	44	W10832958	Element, Heater
11	W10314171	Roller, Support	27	8066168	Assembly, Lint Duct	45	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)
12	W10359272	Shaft, Drum Roller - Left Hand Thread	28	489463	Screw			
13	3934666	Nut, Hex	29	W10345456	Clip, Spring			
14	W10545923	Assembly, Drum	30	W10349492	Wheel, Blower			
15	697693	Baffle, Drum	31	697770	Seal, Plate Cover			
16	W10219342	Screw	32	W10135254	Housing, Blower			
			33	3392519	Fuse, Thermal (91C)			
			34	W10131836	Thermostat			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

72017	White
-------	-------

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

799344	White (Uncut)
--------	---------------

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

350930	White
350938	Gray Primer

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

4392067	Kit, Dryer Repair
285875	Kit, Security
8522199	Kit, Dryer Vent Testing