




30" RADIANT TOUCH COOKTOP

MODELS:

JEC4430KB01 (Black)

JEC4430KS01 (Stainless)

COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6	W11115981	Appliance Manager, Expansion	12	W11102056	Shield, Heat
	W11439183	Installation Instructions	7	W11296739	Appliance Manager, Copernicus	13	4455917	Bracket, Cooktop Mounting
	W10351318	Instructions, Undercounter Install	8	W11242976	Pad, Insulation	14	3400093	Screw
	W11439184	Owner's Manual	9	W11420425	UI Assembly	15	7101P426-60	Screw
	W11238372	Diagram, Wiring	10		Box, Burner (Not Serviced)	16	W11177346	Top, Foam (Heat Shield)
2		Cooktop	11	W10298145	Element (4500W) (Left Front)	17	W11110713	Rail, Vertical
	W11121005	Black		W10342780	Element (1300W) (Left Rear & Right Rear)	18	W11110715	Rail, Horizontal
	W11121006	Stainless						FOLLOWING PARTS NOT ILLUSTRATED
3	W10422108	Assembly, Trim (For Stainless Models)				W11110558		Harness, Main
4		Cover, Win Port (Not Serviced)		W11117008	Element (3200W) (Center Rear)	3192439		Seal, Limiter
5	W10225448	Spring, Element				8286642		Tape, Foam
						W11160362		Insulation, Cooktop

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		ACCESSORIES
	W10355016	Cleaner, Stainless Steel