




REFRIGERATOR

MODELS:

JUDFP242HM11 (Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	W11568783	Switch, Case	17	W11371095	Screw
	W11467322	Energy Guide	9	W11265587	Switch, Door	18	4344763	Leg, Leveling
	W10772894	Tech Sheet	10	W11630433	Cover Assembly, Evaporator	19	W11568948	Assembly, Separator
	W11357308	Use and Care Guide	11	W11568950	LED	20	W11312450	Cover, LED
2	W10774183	Screw	12	W11568787	Connector, Cover	21	W11359415	Fuse, Temperature
3	W11599889	Rail Assembly, Left Hand	13		Cabinet (Not a Servicable Part)	22	W11568776	Cover Piece, Evaporator
4	W11599890	Rail Assembly, Right Hand	14	W11568794	Assembly, Switch Box	23	W11568786	Switch, Door
5	W10621524	Screw	15	W11371097	Screw	24	W11568792	Assembly, Trim
6	W10204809	Screw	16	W11263845	Defrost Heater and Holder			
7	W11359416	Defrost Holder and Heater						


UPPER DRAWER PARTS



UPPER DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11630376	Drawer Box Assembly, Upper	10	W11594165	Wrap, Stainless Steel	19	W11568841	Lamp Cover
2	W11568835	Mat, Upper Drawer	11	W11568838	Door Gasket, Short	20	W10204920	Nut
3	W11599884	Drawer Partition	12	W11568839	Plate, Door Handle	21	W11360665	Gasket, Sash (Top/Bottom)
4	W10772902	Stud, Mounting	13	W10204866	Screw, Handle	22	W11568934	Insulation, Door
5	W11568837	Gasket, Door	14	W11312450	Cover, LED	FOLLOWING PARTS NOT ILLUSTRATED		
6	W11568830	Top Foamed Door Assembly	15	W11604678	Control Panel Assembly			
7	W10319183	Screw	16	W11576360	Harness	W11630391	Assembly, Complete Door	
8	W10204809	Screw	17	W11568842	Support, Lead Wire			
9	W10204810	Screw	18	W10204808	Screw			


LOWER DRAWER PARTS



LOWER DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11630379	Drawer Box Assembly, Lower	7	W10319183	Screw	15	W11568796	Plate, Push
2	W11568945	Mat, Lower Drawer	8	W10204809	Screw	16	W11568934	Insulation, Door
3	W11630371	Drawer Partition	9	W10204810	Screw			FOLLOWING PARTS NOT ILLUSTRATED
4	W11360665	Gasket, Sash (Top/Bottom)	10	W11594165	Wrap, Stainless Steel			
5	W11568947	Gasket	11	W10319185	Screw	W11630420		Assembly, Complete Door
6	W11568937	Door Assembly, Lower	12	W11422825	Name Plate			
			13	W10204920	Nut			
			14	W11568838	Door Gasket, Short			

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11576947	Clamp, Cord	11	W10805035	Drier (Service Drier Without Dye)	20	W11498145	Cord, Power
2	W11371097	Screw				21	W11360592	Stopper
3	W11360241	Water Pan, Evaporator	12	W11265569	Clamp	22	W11422771	PTC Thermistor
4	W11375763	Screw	13	W11531824	Compressor	23	W11568820	Cover
5	W11568810	Main PCB	14	W11568812	Protector, Motor			REFRIGERANT
6	W11577175	Tag, Power Cord	15	W11568821	Panel, Cover			CHARGE
7	4344826	Screw	16	W11360590	Cover, Side			52 grams (R600a)
8	W11265570	Washer	17	W11360595	Compressor, Rubber			
9	W11313206	Cover, PCB	18	4344780	Bolt, Compressor			
10	W11360536	Assembly, Fan Motor	19	W11360596	Mount, Compressor			