




# USER MANUAL


SANDWICH PREP

## KoolMore Refrigerated Salad and Sandwich Prep Table

**Models:** KM-MPTR27-1D, KM-MPTR36-2D, KM-MPTR60-2D, KM-MPTR70-3D,  
KM-PTR27-1D, KM-PTR36-2D, KM-PTR46-2D, KM-PTR60-2D  
KM-PTR70-3D




KM-MPTR27-1D



KM-PTR46-2D

***Before using, please read the operating instructions carefully to ensure proper application and achieve satisfactory results.***


For any service-related issues, please contact us:

 718-576-6342

 [support@koolmore.com](mailto:support@koolmore.com)

## Stay informed with the latest information for your KoolMore Appliance.

Scan the QR code above to access the most recent user manual on our website, which is constantly being updated and improved.



**If you need any assistance or have questions, our customer support team is here to help.**

**P- 718-576-6342 E- [Support@koolmore.com](mailto:Support@koolmore.com)**

Please write down the model number and serial number below for future reference. Both numbers are located on the rating label on the back of your unit or inside of the unit and are needed to obtain warranty service. You may also want to staple your receipt to this manual as it is the proof of your purchase and may also be needed for service under warranty.

Model Number: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Date of Purchase: \_\_\_\_\_

To better serve you, please do the following before contacting customer service:

If you received a damaged product, immediately contact the retailer or dealer that sold you the product.

Read and follow this instruction manual carefully to help you install, use, and maintain your unit.

Refer to the Troubleshooting section of this manual as it will help you diagnose and solve many common issues.

# Safety

<b>Safety</b> .....	<b>4</b>
<b>Installation</b> .....	<b>5</b>
<b>Maintenance</b> .....	<b>8</b>
<b>Troubleshooting</b> .....	<b>9</b>
<b>Warranty</b> .....	<b>10</b>

# SAFETY

## **CAUTION FOR SAFETY**

Leave enough space between the wall, the cabinet, and the ceiling; do not completely seal the back part of the cabinet. Prepare an air vent to the outside.

**CAUTION:** The cabinet needs more than 8 inches of space from the wall. Please remove all packaging from the bottom to allow heat radiation and avoid fire.

It is prohibited to store flammable or volatile chemicals, as they may lead to explosions.

An individual single-phase socket must be used and reliably connected to a grounding wire.

**CAUTION:** Do not connect the grounding wire to a water or gas pipe.

Do not subject the cabinet to hard collisions or intense vibrations during transportation. The inclination of the cabinet should not exceed 45°.

Please refer to the Troubleshooting references when the unit encounters problems. Do not attempt to solve the problem on your own; consult a certified technician only.

**DANGER –** Risk of fire or explosion. Flammable refrigerant used. Do not puncture refrigerant tubing. To be repaired only by trained service personnel.

**CAUTION –** Risk of fire or explosion. Flammable refrigerant used. Consult the repair manual/owner's guide before attempting to service this product. All safety precautions must be followed. Dispose of it properly in accordance with federal or local regulations. Follow handling instructions carefully to avoid puncturing refrigerant tubing. Keep all ventilation openings in the appliance enclosure or built-in structure clear of obstructions. Servicing must be performed by factory-authorized service personnel to minimize the risk of ignition due to incorrect parts or improper service.