



VEFTF2412RBK spare parts list

No.	Homa Code	Description of Spare Part	Quantity
2	2208100413	Door hinge screw cover	1
3	2301400155	Upper door hinge	1
4	2208200084	Upper door hinge cover,left	1
5	2208100412	Upper door hinge cover,right	1
6	3031400040	Middle door hinge	1
8	2106100239	Freeze shelf assembly	1
9	3039900316	Water balcony of heater	1
10	2400300032	Fin evaporator	1
11	2500700044	Defrost heater	1
12	3050200087	Connecting wire of fuse	1
13	2107120016	Freeze air duct	1
13.1	3059900004	Fan motor	1
13.2	2208200052	Front cover plate of freeze air duct	1
13.3	2209100065	Back cover plate of freeze air duct	1
13.4	2208100219	Freeze air duct knob	1
13.5	3071000311	Freeze air duct foam	1
13.6	2208200085	Regulated pick	1
13.7	20122990721	Fan motor mounting cover	1
16	2207500100	Freeze door balcony	2
17	2100292600	Upper door	1
17.1	2200200489	Upper door gasket	1
17.3	2208510073	Upper door right aid closer	1
17.4	2208510007	Upper door left aid closer	1
18	2100293473	Lower door	1
18.1	2200200490	Lower door gasket	1
18.2	2208510071	Lower door right aid closer	1
18.3	2208510072	Lower door left aid closer	1
19	2107120017	Fridge air duct assembly	1
20	2107130030	Main control board assembly	1
20.1	2208101804	Main control board mounting box	1
20.2	2208101805	Main control board cover	1
20.3	2500200024	Connecting line W20-72	1

20.4	2500200025	Connecting line W20-73	1
20.5	2500300019	Main control board	1
21	2107120354	Fridge air duct	1
21.1	2208200117	Fridge air duct cover	1
21.2	2701000277	Upper foam Fridge air duct	1
21.3	2701000278	Lower foam Fridge air duct	1
21.4	2209100059	Display film	1
21.5	3050400025	LED light board	1
22	2208500094	Drain box	1
25	2207500103	Small balcony	2
26	2207500104	Bottom balcony	1
27	2106100240	Fridge shelf assembly	2
28	2106120678	Cover of crisper drawer	1
29	2106140011	Crisper drawer assembly	1
30	2301400213	Lower door hinge assembly,right	1
31	2207700062	Higher leveling foot	1
33	20122990026	higher foot	1
34	2107100001	Compressor bracket	1
35	3050100135	Power supply cord	1
36	3050200095	Earthing wire of compressor	1
37	2400100371	Compressor	1
38	20114070006	Connecting tube	1
39	2400500047	Process tube	1
40	2400500045	Drier filter	1
41	2207700181	Drain pan	1
42	2207700024	Drain pipe	1
43	2501100002	Door switch	1
48	2207500889	Bottom balcony	1
49	2209100066	Lamp cover	1
300	2700503099	Trademark	1
301	2700157780	Carton	1

VEFTF2412RSL spare parts list

No.	Homa Code	Description of Spare Part	Quantity
2	2208200119	Door hinge screw cover	1
3	2301400155	Upper door hinge	1
4	20122080161	Upper door hinge cover,left	1
5	2208100246	Upper door hinge cover,right	1
6	3031400040	Middle door hinge	1
8	2106100239	Freeze shelf assembly	1
9	3039900316	Water balcony of heater	1
10	2400300032	Fin evaporator	1
11	2500700044	Defrost heater	1
12	3050200087	Connecting wire of fuse	1
13	2107120016	Freeze air duct	1
13.1	3059900004	Fan motor	1
13.2	2208200052	Front cover plate of freeze air duct	1
13.3	2209100065	Back cover plate of freeze air duct	1
13.4	2208100219	Freeze air duct knob	1
13.5	3071000311	Freeze air duct foam	1
13.6	2208200085	Regulated pick	1
13.7	20122990721	Fan motor mounting cover	1
16	2207500100	Freeze door balcony	2
17	2100292608	Upper door	1
17.1	2200200421	Upper door gasket	1
17.3	2208510073	Upper door right aid closer	1
17.4	2208510007	Upper door left aid closer	1

18	2100292423	Lower door	1
18.1	2200200422	Lower door gasket	1
18.2	2208510071	Lower door right aid closer	1
18.3	2208510072	Lower door left aid closer	1
19	2107120017	Fridge air duct assembly	1
20	2107130030	Main control board assembly	1
20.1	2208101804	Main control board mounting box	1
20.2	2208101805	Main control board cover	1
20.3	2500200024	Connecting line W20-72	1
20.4	2500200025	Connecting line W20-73	1
20.5	2500300019	Main control board	1
21	2107120354	Fridge air duct	1
21.1	2208200117	Fridge air duct cover	1
21.2	2701000277	Upper foam Fridge air duct	1
21.3	2701000278	Lower foam Fridge air duct	1
21.4	2209100059	Display film	1
21.5	3050400025	LED light board	1
22	2208500094	Drain box	1
25	2207500103	Small balcony	2
26	2207500104	Bottom balcony	1
27	2106100240	Fridge shelf assembly	2
28	2106120678	Cover of crisper drawer	1
29	2106140011	Crisper drawer assembly	1
30	2301400213	Lower door hinge assembly,right	1
31	20122990727	Higher leveling foot	1
33	20122990781	higher foot	1
34	2107100001	Compressor bracket	1
35	3050100135	Power supply cord	1
36	3050200095	Earthing wire of compressor	1
37	2400100371	Compressor	1
38	20114070006	Connecting tube	1
39	2400500047	Process tube	1
40	2400500045	Drier filter	1
41	2207700181	Drain pan	1
42	2207700024	Drain pipe	1
43	2501100002	Door switch	1
48	2207500889	Bottom balcony	1
49	2209100066	Lamp cover	1
300	2700503099	Trademark	1
301	2700157781	Carton	1

VEFTF2412RWH spare part list

No.	Homa Code	Description of Spare Part	Quantity
2	2208200126	Door hinge screw cover	1
3	2301400155	Upper door hinge	1
4	20122080138	Upper door hinge cover,left	1
5	2208100313	Upper door hinge cover,right	1
6	3031400040	Middle door hinge	1
8	2106100239	Freeze shelf assembly	1
9	3039900316	Water balcony of heater	1
10	2400300032	Fin evaporator	1
11	2500700044	Defrost heater	1
12	3050200087	Connecting wire of fuse	1
13	2107120016	Freeze air duct	1
13.1	3059900004	Fan motor	1
13.2	2208200052	Front cover plate of freeze air duct	1
13.3	2209100065	Back cover plate of freeze air duct	1

13.4	2208100219	Freeze air duct knob	1
13.5	3071000311	Freeze air duct foam	1
13.6	2208200085	Regulated pick	1
13.7	20122990721	Fan motor mounting cover	1
16	2207500100	Freeze door balcony	2
17	2100292611	Upper door	1
17.1	2200200355	Upper door gasket	1
17.3	2208510073	Upper door right aid closer	1
17.4	2208510007	Upper door left aid closer	1
18	2100292157	Lower door	1
18.1	2200200356	Lower door gasket	1
18.2	2208510071	Lower door right aid closer	1
18.3	2208510072	Lower door left aid closer	1
19	2107120017	Fridge air duct assembly	1
20	2107130030	Main control board assembly	1
20.1	2208101804	Main control board mounting box	1
20.2	2208101805	Main control board cover	1
20.3	2500200024	Connecting line W20-72	1
20.4	2500200025	Connecting line W20-73	1
20.5	2500300019	Main control board	1
21	2107120354	Fridge air duct	1
21.1	2208200117	Fridge air duct cover	1
21.2	2701000277	Upper foam Fridge air duct	1
21.3	2701000278	Lower foam Fridge air duct	1
21.4	2209100059	Display film	1
21.5	3050400025	LED light board	1
22	2208500094	Drain box	1
25	2207500103	Small balcony	2
26	2207500104	Bottom balcony	1
27	2106100240	Fridge shelf assembly	2
28	2106120678	Cover of crisper drawer	1
29	2106140011	Crisper drawer assembly	1
30	2301400213	Lower door hinge assembly,right	1
31	20122990812	Higher leveling foot	1
33	20122990023	higher foot	1
34	2107100001	Compressor bracket	1
35	3050100135	Power supply cord	1
36	3050200095	Earthing wire of compressor	1
37	2400100371	Compressor	1
38	20114070006	Connecting tube	1
39	2400500047	Process tube	1
40	2400500045	Drier filter	1
41	2207700181	Drain pan	1
42	2207700024	Drain pipe	1
43	2501100002	Door switch	1
48	2207500889	Bottom balcony	1
49	2209100066	Lamp cover	1
300	2700503099	Trademark	1
301	2700157943	Carton	1