




Dishwasher

MODELS:

WDT531HAPM0 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5		Access Panel (Includes Hardware)	12		Handle Assembly
	W11655291	Energy Guide					W11554913	Stainless
	W11532445	Owners Manual		W10441006	Black	13	W10519755	Insulation, Toe Panel
	W11532444	Tech Sheet	6	W10884775	Badge	14	W10693137	Screw, Set
2		Arm, Hinge	7	8268961	Sleeve, Friction	15	W10316572	Screw
	W11484017	Left Hand	8	W10692757	Barrel Nut, Front Panel	16	W11049903	Stud, Mounting
	W11484018	Right Hand	9	W11504190	Light, Pipe	17	W10711884	Screw
3	W10803537	Stiffener, Door	10	3400071	Screw	18		Fastener
4		Panel, Front (Includes 6, 8, 9, 15 & 16)	11	W10315897	Insulation, Front Panel		W10503548	Black
	W11528195	Stainless						


CONTROL PANEL AND LATCH PARTS



CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly	3	W10825369	Brace, Connector	6	W10653840	Latch Assembly (Includes Switch)
	W11504635	Black	4	W11665213	Control, Electronic			
2	W10825638	Box, Connector	5	W10348408	Screw	7	W10177098	Screw

INNER DOOR PARTS



INNER DOOR PARTS

Illus.
No.

Part No.

Description

1	W10348409	Screw
2	W11050927	Seal, Console/Door
3	W11631034	Inner Door Assembly

Illus.
No.

Part No.

Description

4	W10920683	Door Bottom, Seal
5	W11574971	Vent Assembly
6	W11476843	Screw


Illus.
No.

Part No.

Description

7	W11531479	Deflector, Vent
8	W10620296	Dispenser Assembly
9	W11595230	Wiring Harness
10	W11184028	Gasket, Vent


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	370445	Clamp, Hose	6	371505	Clamp, Hose	10	304231	Screw
2	W10769066	Inlet Hose	7	W11669944	Fill Valve Assembly	11	W10195039	Switch, Overfill Control
3	W10195536	Inlet, Water (Also Order Item 4)	8	W10786175	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)	12	W10316267	Standpipe, Overfill
4	8531323	Gasket				13	W10346525	Float & Retainer Assembly
5	W10508676	Nut, Inlet (Also Order Item 4)	9	W10545278	Drain loop with check valve assembly	14	W10195037	Lever, Overfill Switch


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11467711	Tub Assembly (Includes Heater Assembly)	11	3400892	Screw	21	W10732961	Bracket, Heater Support
2	W11656602	Shield, Thermostat	12	8268991	Cover, Terminal Box	22	W10441445	Heater Element Assembly
3	W11425053	Seal, Tub	13	W10866979	Shield, Tub Sound			(Includes Heater Washer & Nut)
4	W10341745	Screw	14	W11525335	Clip, Thermostat			NOTE: If heater element is removed, it must be replaced.
5	W11296374	Screw	15	3371618	Thermostat			
6	8269145	Bracket, Undercounter	16	W10544004	Strike, Latch			
7	W11623675	Support, Bottom	17	3378128	Washer, Pronged Cup			
8	W10619352	Leveler, Leg	18	3400014	Screw, Grounding	23	W10277003	Screw
9	W10337934	Spring, Door Balance	19	W10819539	Sound Insulation, Bottom	24	489470	Screw
10	8575897	Wheel Assembly	20	8268990	Bushing, Door Spring	25	8270018	Wheel


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10455271	Cover, Outlet	6	W10372113	Tab, Sump	13	8269146	Clamp, Hose
2	W10482462	Sump With Seal (Also Order Items 12 & 16)	7	W10789806	Filter Cup Assembly	14	W10195086	Motor, Isolator
3	W10463906	Screen	8	W10724439	Pump, Drain	15	W11521438	Motor (Also Order Items 12 & 16)
4	W10348407	Screw	9	8269144	Hose, Drain	16	W10445975	Hose Assembly (Includes 2 Clamps)
5	W11525187	Sump & Motor Assembly	10	370445	Clamp, Hose	17	W10491331	Sprayarm
			11	W11525024	Sensor, Temperature			
			12	W11182008	Grommet			


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11462355	Feed Tube Assembly	3	W10498900	Sprayarm
2	W10165274	Screw	4	W10340681	Manifold


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10826745	Dishrack, Upper	4	8565925	Stop, Track (Non-Removable)	5	W10845760	Mount, Wheel Assembly
2	W10306228	Track, Spacer				6	3379676	Wheel
3	3385089	Track, Dishrack						

LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8561705	Dishrack, Lower
2	8268645	Wheel & Transport Assembly
3	8562045	Basket, Silverware (Assembly)

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
	8171657	Black
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft.
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)
	8171477	Floor Mount Kit
	8212560	Side Mount Kit