




**FOOD WASTE DISPOSER
(1/2-Horsepower Continuous Feed)**

MODELS:

WG1202XH1

DISPOSER PARTS



DISPOSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	2	W11315641	Disposer, Complete (WG1202XH)	3	4211300	Stopper Assembly
	W11112250	Use & Care Guide				4	8174355	Kit, Installation