




GAS DRYER

MODELS:

WGD500CMW1 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9	W11374901	Encoder, Mega Assembly	17	W10773242	Screw
	W11361424	Owners Manual				18	W10662472	Collar, Lint Chute
	W11565129	Tech Sheet	10	688983	Screw	19	W11445460	Assembly, Fascia
	W11423864	Quick Start Guide	11	3348629	Screw	20	9740848	Screw
2	W11551859	HMI Harness	12		Top	21	343641	Screw
3	W11606407	Appliance Control Unit (ACU)		W10613389	White			
4	W10775189	Panel, Rear	13	W10298336	Nut, "U"			
5	W11568018	Harness, Main	14		Assembly, Control Knob			
6	8312709	Clip, Console		W11406489	Chrome			
7	693995	Screw	15		Assembly, Console			
8		Lint Screen		W11406485	White			
	W11538108	White	16	8536939	Clip, Spring			


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3390631	Screw	19	98234	Clip, Ground	36		Door, Outer
2	343641	Screw	20	8066092	Lock, Front Top		W10714510	White
3	693995	Screw	21		Panel, Front	37		Handle, Door
4	W10841728	Seal, Spill Guard		W10664698	White		W10714516	White
5	8558833	Cover, Terminal Block	22	W10641296	Hinge, Top	38	W10803476	Assembly, Seal and Bearing
6	W10121316	Clamp, Motor Mount	23	685203	Clip, Felt Pad	39		Plug, Front Panel
7	W11598681	Panel, Rear	24	W11224630	Assembly, Door Catch		8564457	White
8	W10567345	Plug, Strike	25	W10730752	Seal, Door	40	W11564940	Burner Assembly (60 Hz) (Type 1)
9	W10529198	Cover, Door Catch	26	691366	Idler Assembly	41	W10316529	Seal, Foam
10	W11590193	Switch, Door	27	342055	Screw	42	W10316619	Seal, Spill Guard
11	697773	Screw	28		Assembly, Hinge and Pin	43	W10529197	Bezel, Door Catch
12	W10869141	Cord, Power		W10362431	White	44	W10727507	Clamp, Pipe
13	341029	Clamp, Pipe	29	W10396039	Motor Assembly 60 Hz.	45	W10641295	Bracket, Rear
14		Hinge Hole Cover	30	8066184	Pulley, Motor	46	W10836094	Pad, Sound
	W11308618	White	31	3387610	Belt, Drive	47	3401805	Bracket, Idler
15	W10775448	Clip, Front Panel	32	3400500	Bolt			
16	W10779369	Foot, Dryer	33	W11224633	Strike, Door			
17	3401800	Shield, Belt Assembly	34	3401801	Base, Motor			
18		Cabinet	35	W10463967	Door, Inner			
	8530603	White						

BULKHEAD PARTS




BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798024	Assembly, Lint Chute	16	W11050897	Kit, Thermal Cut-Off (Includes Thermostat)	29	348197	Washer
2	489463	Screw	17	3390647	Screw	30	W10298789	Nut, Hex
3	3388703	Washer	18	8066049	Funnel, Burner	31	W10714469	Bulkhead
4	347139	Seal, Lint Chute	19	339956	Seal	32	338906	Sensor, Radiant
5	90767	Screw	20	3403636	Baffle, Drum (Short)	33	692490	Baffle, Drum (Long)
6	W10389567	Shield, Exhaust	21	8578825	Bracket, Drum Light	34	692526	Bearing, Ring
7	3392519	Fuse, Thermal (91C)	22	90296	Nut, Push On	35	W10219342	Screw
8	W11424720	Pad, Sensor	23	3402841	Lens, Drum Light	36	W10856781	Seal, Rear Drum
9	8577274	Thermistor	24	W11032820	Bracket, Support	37	W10757750	Assembly, Drum (Complete)
10	W10709771	Wheel, Blower	25	W10512946	Washer, Tri Ring	38	3406124	Bulb, Light
11	8577230	Housing, Blower	26	W10359270	Shaft, Drum Roller - Left Hand Thread	39	W10214261	Socket, Light
12	3398161	Clip, Heater Box	27	W10359269	Shaft, Drum Roller - Right Hand Thread			
13	343641	Screw	28	3397590	Roller, Support			
14	8530285	Box, Heater (96C)						
15	W10754607	Thermostat, High Limit SPST (180F)						

BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11564940	Burner Assembly (60 Hz) (Type 1)	7	693986	Base, Burner	13	326049536	Screw
2	688617	Tube, Burner	8	3387057	Screw			Following Parts Not Illustrated
3	694298	Bracket, Ignitor	9		Orifice, Burner			
4	686590	Ignitor		234826	Type 1 (Natural)	W11581316		Kit, LP Conversion
5	W10366705	Screw	10	W11564943	Valve, Gas (60 Hz)			
6	343641	Screw	11	W10295523	Pipe Plug			
			12	W10328463	Coil (60 Hz)			

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	279948	Kit, Dryer Repair
	346764	Kit, Hold Down
	W10242307	Washer, Hose
	3976300	Washer, Inlet Hose
	W10336486	Connector, Hose -"Y"
	W10636192	Dry Rack

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

72017 White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

350930 White

350938 Gray Primer

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

799344 White (Uncut)